

Date	Release Note	DW(8/11)	MS(7/17)	THH(8/28)	IAQ(8/18)	SL(7/29)	AL(7/29)	WL(7/17)
20191118	Support downlink configure	O	O	O	O	O	O	O
20191129	Modify keep alive interval to 5 mins.	X	X	X	O	X	X	X
20191104	The default minimum "keep-alive time" is changed to 15 seconds	O	X	X	X	X	X	X
20191225	Adjust interrupt flow when the sensor is in no water status(keep 30 sec).	X	X	X	X	X	X	O
20200109	Modify the battery voltage detection time by 10 minutes.	O	O	O	O	O	O	O
20200114	Add IN865 ISM Band.	O	O	O	O	O	O	O
20200131	Modify decibel range and threshold range from 40 to 100.	X	X	X	X	O	X	X
20200427	Modify test mode timing from (3,3,6,6) to (2,2)	O	O	O	O	O	O	O
20200518	Modify new sensor parameter from 0.6 to 0.45.	X	X	X	X	X	O	X
20200609	Add AS923_2 ISM Band	O	O	O	O	O	O	O
20200615	Modify Rxparameter MAC command flow to avoid set FSK datarate.	O	O	O	O	O	O	O
20200708	Implement data rate adaptation for confirmed uplink retransmissions.	O	O	O	O	O	O	O
	The confirmed uplink count will add 1 when the sensor send confirmed uplink every 8 times.	O	O	O	O	O	O	O
	Modify ADRACKReq related flow.	O	O	O	O	O	O	O
	Fix AS923 ADRACKReq issue when UplinkDewellTime = 1.	O	O	O	O	O	O	O
	Fix new FSK Channel issue.()	O	O	O	O	O	O	O
	Fix LinkADRRequest enable all channels issue.	O	O	O	O	O	O	O
	Fix KPN new channel issue.	O	O	O	O	O	O	O
	Add KR920 LBT ISM Band.	O	O	O	O	O	O	O
20200806	Fix Bug 4073 "Switch to Moving Mode from Stationary Mode, Always show the "Outdoor Mode"."	X	X	X	X	X	X	X
	Fix Bug 4074 "After setup the "Stationary Threshold" to 20, Industrial Tracker failed to switch to Stationary Mode."	X	X	X	X	X	X	X
	Fix Bug 4222 "Failed to trigger the uplink anymore when config the GPS mode under stationary status."	X	X	X	X	X	X	X
	Fix Bug 4223 "Failed to trigger the uplink anymore when config the GPS mode under moving status."	X	X	X	X	X	X	X
	Fix Bug 4224 " The battery capacity bit was removed on the reference manual. "	X	X	X	X	X	X	X
20200814	Try to edit the g-sensor timeout value under the moving mode, sometimes DUT will hang up.	X	X	X	X	X	X	X