

1	NFC button – used to scan an NFC tag to start a session.
2	Removable belt clip
3	Status LED/Bumpers – provides extra drop protection and displays different colors for monitoring the device status.
4	Charging pads – used to charge the VENUE Tag with the charging cradle.
5	USB port – used to charge the VENUE Tag with a USB charging cable.
6	Recessed power button – used to power on/off the VENUE Tag.

## 1. Charging

The VENUE Tag can be charged in two ways:

- Put the VENUE Tag in the charging cradle.
- Plug the USB charging cable to the USB port of the VENUE Tag.

Note:

- When the tag is in charging mode, the LEDs will flash yellow at 0.5Hz (1 second on and 1 second off).
- VENUE Tag will get turned on automatically with any of the above two charging methods.

## 2. Turning on the VENUE Tag


- Put the VENUE Tag in the charging cradle or plug the USB charging cable to the USB port of the VENUE Tag to turn it on.
- Alternatively, press and hold the recessed power button to turn it on.

Note:

- When VENUE Tag is turned on, if Wi-Fi has not been configured, the LEDs will flash yellow with a periodic pattern of 2 long-period flashes followed by 2 short-period flashes.

## 3. Connecting the VENUE Tag to Wi-Fi

1. Connect to the VENUE Tag's Wi-Fi hotspot using an Android device
2. The hotspot SSID name will be: VenueTag-xxxx
3. Open the VENUE Android Wi-Fi configuration app
4. Enter the Wi-Fi AP SSID/password and click "Confirm"
  - o The VENUE Tag will get the Wi-Fi AP info, configure itself, reboot and try to connect to the Wi-Fi AP configured.



## 4. OTA (Over-The-Air) Update

The VENUE Tag has the ability to update its FW through OTA (Over-The-Air) update.

When it is being charged in the charging cradle or through the USB port, the VENUE Tag will check if any newer version of the software is available. If new software is available, it will automatically download and update itself.

Note:

- When the VENUE Tag in the charging state, the LEDs will flash yellow at 0.5Hz (1 second on and 1 second off). When the software is being updated, the LEDs will flash blue at 1Hz (0.5 second on and 0.5 second off) until the process is done.

## 5. Additional Instructions

Please refer to the VENUE Tag user guide for more detailed instructions including:

- How to start a session
- How to stop a session
- VENUE Tag LED states

### Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### IMPORTANT NOTE:

##### Radiation Exposure Statement:

The product complies with the US portable RF exposure limit set forth for an uncontrolled environment and are safe for intended operation as described in this manual. The further RF exposure reduction can be achieved if the product can be kept as far as possible from the user body or set the device to lower output power if such function is available.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Country Code selection feature to be disabled for products marketed to the US/CANADA

Operation of this device is restricted to indoor use only

This equipment should be installed and operated with minimum distance 5mm between the radiator & your body.

### Industry Canada statement:

*This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:*

- (1) *This device may not cause interference*
- (2) *This device must accept any interference, including interference that may cause undesired operation of the device*

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

#### Caution:

The device for operation in the band 5150–5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems;

#### Avertissement:

les dispositifs fonctionnant dans la bande de 5150 à 5250MHz sont réservés uniquement pour une utilisation à l'intérieur afin de réduire les risques de brouillage préjudiciable aux systèmes de satellites mobiles utilisant les mêmes canaux;

#### Radiation Exposure Statement:

The product complies with the Canada portable RF exposure limit set forth for an uncontrolled environment and are safe for intended operation as described in this manual. The further RF exposure reduction can be achieved if the product can be kept as far as possible from the user body or set the device to lower output power if such function is available.

This equipment should be installed and operated with minimum distance 5mm between the radiator & your body.

#### Déclaration d'exposition aux radiations:

Le produit est conforme aux limites d'exposition pour les appareils portables RF pour les Etats-Unis et le Canada établies pour un environnement non contrôlé. Le produit est sûr pour un fonctionnement tel que décrit dans ce manuel. La réduction aux expositions RF peut être augmentée si l'appareil peut être conservé aussi loin que possible du corps de l'utilisateur ou que le dispositif est réglé sur la puissance de sortie la plus faible si une telle fonction est disponible.

Cet équipement doit être installé et utilisé avec un minimum de 5mm de distance entre le radiateur et votre corps.

